Software Roadmap

To install DG/UX and other system software, use the manuals listed below.

Installing the system

Installing the DG/UX™ System

This manual guides you through the system installation process.

Mass-storage devices

If your system includes a mass-storage device, refer to the manual for your device:

CLARiiON™ Disk-Array Storage System

CLARiiON™ Tape-Array Storage System

Managing a network

For setting up and managing network software, refer to these manuals:

Managing TCP/IP on the DG/UX™ System

Managing ONC™/NFS® and Its Facilities on the DG/UX™ System

Customizing the system

Customizing the DG/UX™ System

This manual describes how to add user accounts, OS and X clients, additional packages, terminals, printers, and secondary releases.

NOTE: To fully configure your system, you may also need to refer to hardware manuals for the devices you have installed.

Managing the system

Managing the DG/UX™ System

This manual provides an introduction to system administration and a comprehensive guide to managing your DG/UX system.

(, DataGeneral

Installation Roadmap

069–701084–04

A Guide to
AViiON® Systems
Installation Documentation

Hardware Roadmap

Setting up your hardware

Refer to the *Installing* or *Setting Up* manual for your AViiON® workstation or computer.

This manual guides you through the entire setup process.

(The *Getting Started* guide for your system gives an overview of the installation procedure.)

Installing devices

The following manuals describe how to install additional devices. Your workstation/computer manual identifies the ones you need.

AV/Alert modem and other modems

Using AViiON® Diagnostics and the AV/Alert℠ Diagnostic Support System

Mass-storage chassis

Refer to the manual for any mass-storage devices you install:

CLARiiON™ Disk-Array Storage System

CLARiiON™ Tape-Array Storage System

CSS3/DC Subsystem

Model 10565 Peripheral Housing Unit

VMEbus options

Setting Up and Installing VMEbus Options in AViiON® Systems

Other devices

For other devices (such as terminals, or tape and disk drives), consult the manuals that ship with those devices.

Configuring firmware

Refer to your system's *Setting Up* or *Operating* manual for information on setting firmware options.

You can use firmware options as part of your hardware testing or software customization.

Testing installed hardware

If you want to test your hardware system beyond the built-in power-up tests, use this manual. Additional stand-alone tests are optional.

Using AViiON® Diagnostics and the AV/Alert℠ Diagnostic Support System

Testing installed hardware

To Software Roadmap ▶